



PCASE Installation and Configuration Guide


1. The PCASE installation file is available at the link below.
<https://transportation.erdc.dren.mil/pcase/software.aspx>.
2. Download, open the zip File and extract the PCASE 7.0.1 Setup.exe file
3. Installation requires administrator privileges, and it is assumed PCASE is being installed on a NIPR system.
4. Program Default Install: The PCASE application installs to C:\Program Files (x86)\EMS folder. We recommend the default install location. If there is a need to change the install location, contact the PCASE Program Manager, George VanSteenburg 402-326-5646



5. Default Data Folder: The default location for the data folder is C:\Users\Public\Documents\SMS User Data. The assumption is that the user has full permission to this folder and that a database created in this folder is publicly releasable unclassified information. If a database is considered controlled unclassified information (CUI) then change the data directory to a location that the user has read/write permissions to and that is not publicly accessible. The process for making this change is outlined below.



- a. In PCASE, go to Help>>Program Version




b. Select Move User Data Folder




c. Select Yes




d. Brows to a location with read/write permissions accessible to the user e.g., C://Users/user name/documents and create and SMS folder there.



- e. Select Ok (screen shot above), select Save Configuration and Exit, select Ok



- f. When prompted to Move User Data, select NO



- g. You get a message, this tool will now close, select Ok
6. Open PCASE and create a database following the "Getting Started" guidance. The recommended best practice is to include the classification level in the name of the file and whenever exporting a database.